

PARTS LIST

BC3021H-RS-01

CONTENTS


1. MAIN BODY	1 ~ 2
2. GEARCASE.....	3 ~ 4
3. ENGINE.....	5 ~ 8
4. CARBURETOR, FUEL TANK	9 ~ 12
5. ACCESSORIES	13 ~ 14

2012. 09.




P/N 523302-1

1. BC3021H-RS-01
MAIN BODY




Ref. No.	Part No.	Part Name	Q'ty	Remarks
1-1	363965	BC3021H-RS-01	1	
1-2	215512	Clutch Case Ass'y	1	Incl.3-9
1-3	214592	Bearing Case	1	
1-4	214161	Bearing	2	#6000ZZ
1-5	054676	Snap Ring	1	#26
1-6	214162	Buffer	1	
1-7	214163	Washer	1	
1-8	092033	Screw	4	M5x15
1-9	214593	Driveshaft Tube Adapter	1	
1-10	261246	Cap Screw	1	M5x25
1-11	054677	Clutch Drum	1	
1-12	219268	Driveshaft Ass'y	1	
1-13	218711	Driveshaft Tube	1	
1-14	215532	Shaft Grip	1	
1-15	215533	Hanging Bracket Ass'y	1	Incl.16
1-16	261762	Cap Screw	1	M5x14
1-17	216935	Bracket Ass'y	1	Incl.18
1-18	261246	Cap Screw	6	M5x25
1-19	231048	Label	1	BC3021H-RS
1-20	223188	Label	1	
1-21	261250	Cap Screw	4	M5x20
1-22	226501	Handle Ass'y-Left	1	Incl.23,24
1-23	226502	Handle	1	
1-24	226503	Grip	1	
1-25	232081	Handle Ass'y-Right	1	Incl.26,27
1-26	223714	Handle	1	
1-27	232082	Throttle Trigger	1	
1-28	231264	Label	1	111dBA
1-29	232086	Safety Cover Ass'y	1	Incl.30-36
1-30	231252	Safety Cover Ass'y	1	Incl.31,32
1-31	227819	Bracket	1	
1-32	221580	Screw	1	4x8
1-33	232087	Bracket Ass'y	1	Incl.34-36
1-34	227822	Bracket	1	
1-35	220632	Cap Screw	2	M6x30
1-36	231704	Washer	2	6x13xt1.0
1-37	231882	String Cutter Ass'y	1	Incl.38-40
1-38	230747	String Cutter	1	
1-39	261250	Cap Screw	1	M5x20
1-40	228325	Nut	1	
1-41	230748	Cover Extention	1	
1-42	228086	Hanging Strap Ass'y	1	

2. BC3021H-RS-01
GEARCASE




Ref. No.	Part No.	Part Name	Q'ty	Remarks
2-1	231880	Gearcase Ass'y	1	Incl.2-17
2-2	225960	Gearcase	1	
2-3	234109	Bolt	1	M8x8
2-4	227990	Bearing	1	#608
2-5	228416	Gear Set	1	
2-6	219087	Cap Screw	1	M5x10
2-7	227991	Bearing	1	#6001DDU
2-8	055185	Snap Ring	1	#28
2-9	227992	Bearing	1	#609
2-10	227993	Bearing	1	#609Z
2-11	228477	Snap Ring	1	#9
2-12	140270	Snap Ring	1	#24
2-13	261246	Cap Screw	1	M5x25
2-14	212986	Boss Adapter	1	
2-15	140275	Clamping Washer	1	
2-16	215547	Stabilizer	1	
2-17	215610	Bolt	1	M8x22,Counterclockwise

2. GEARCASE GT-TURBO




Ref. No.	Part No.	Part Name	Q'ty	Remarks
2-1	232926	Gearcase Ass'y	1	Incl.2-17
2-2	232719	Gearcase	1	
2-3	234109	Bolt	1	M8x8
2-4	261246	Cap Screw	1	M5x25
2-5	210560	Bearing	1	#609
2-6	233332	Gear Set	1	
2-7	232724	Bearing	1	#6203 2RS
2-8	012381	Snap Ring	1	#40
2-9	210560	Bearing	1	#609
2-10	140268	Bearing	1	#609Z
2-11	228477	Snap Ring	1	#9
2-12	140270	Snap Ring	1	#24
2-13	232927	Boss Adapter	1	
2-14	232928	Clamping Washer	1	
2-15	210308	Stabilizer	1	
2-16	215610	Bolt	1	M8x22,Counterclockwise
2-17	219087	Cap Screw	1	M5x10

3. BC3021H-RS-01
ENGINE




Ref. No.	Part No.	Part Name	Q'ty	Remarks
3-1	858770	Engine	1	CE300/50
3-2	286791	Cylinder	1	
3-3	286846	Gasket	1	
3-4	261250	Cap Screw	4	M5x20
3-5	269144	Insulator	1	New gasket required
3-6	267049	Gasket	1	
3-7	265924	Cap Screw	2	M5x25
3-8	283007	Muffler Ass'y	1	Incl.9-12
3-9	283003	Muffler Comp.	1	
3-10	268171	Muffler Tail	1	
3-11	267056	Spark Arrester	1	
3-12	265107	Cap Screw	2	M4x10
3-13	281440	Gasket	1	
3-14	266402	Cap Screw	2	M5x55
3-15	281435	Under Cover	1	
3-16	267191	Cap Screw	1	M5x16
3-17	286707	Top Cover Ass'y	1	Incl.18-21
3-18	281434	Top Cover	1	
3-19	286300	Knob	1	
3-20	261020	Spacer	1	
3-21	261734	Snap Ring	1	#5
3-22	286851	Crankcase	1	
3-23	280488	Bearing	2	PPL 6001
3-24	261492	Oil Seal	1	ISCD12287
3-25	261386	Oil Seal	1	ISCD12227
3-26	055185	Snap Ring	1	#28
3-27	261612	Cap Screw	3	M5x30
3-28	281442	Screen	1	
3-29	268782	Piston	1	
3-30	265067	Piston Ring	2	(2)Required
3-31	265068	Piston Pin	1	
3-32	265225	Bearing,Needle	1	
3-33	261393	Clip,Piston Pin	2	
3-34	265141	Crankshaft/Conn.Rod Ass'y	1	
3-35	267327	Clutch Ass'y	1	Incl.36,37
3-36	267342	Clutch Shoe	2	(2)required
3-37	267345	Spring,Clutch	1	
3-38	264505	Bolt	2	
3-39	261777	Wave Washer	2	
3-40	261189	Washer	2	6x16.5x1.2
3-41	281433	Fan Cover	1	
3-42	261250	Cap Screw	4	M5x20
3-43	287898	Magneto Ass'y	1	Incl.44-48
3-44	287902	Rotor/Fan	1	
3-45	281746	Ignition Coil Ass'y	1	Incl.46-48

3. BC3021H-RS-01
ENGINE




Ref. No.	Part No.	Part Name	Q'ty	Remarks
3-46	269714	Plug Boot	1	
3-47	269715	Connector	1	
3-48	281756	Insulator	1	
3-49	261076	Woodruff Key	1	3x10
3-50	261417	Nut,Rotor	1	M8
3-51	280381	Spacer	2	
3-52	261256	Cap Screw	2	M4x25
3-53	288264	Spark Plug	1	NGK BPMR8Y
3-54	269722	Lead	1	
3-55	268044	Lead	1	
3-56	269189	Grommet	1	
3-57	283476	Recoil Starter Ass'y	1	Incl.58-68
3-58	283477	Recoil Ass'y	1	Incl.59-67
3-59	283504	Reel	1	
3-60	283505	Cam Plate	1	
3-61	283506	Spring	1	
3-62	280931	Spiral Spring	1	
3-63	267213	Screw	1	
3-64	283578	Stater Rope Ass'y	1	Incl.65-67
3-65	283579	Stater Rope	1	
3-66	261725	Starter Grip	1	
3-67	283511	Rope Stopper	1	
3-68	283575	Starter Pawl Ass'y	1	
3-69	284698	Adapter Ass'y	1	
3-70	283391	Cap Screw	2	M4x20
3-71	265726	Cap Screw	4	M4x16
3-72	282096	Cap Screw	1	M4x16WSW
3-73	264588	Clamp	1	
3-74	286143	Label	1	REVERSE2 CE300
3-75	265694	Label	1	
3-76	267561	Label	1	

4. BC3021H-RS-01
 CARBURETOR, FUEL TANK




Ref. No.	Part No.	Part Name	Q'ty	Remarks
4-1	284111	Carburetor Ass'y	1	Incl.2-16 New gasket required
4-2	264155	Pump Body	1	
4-3	262991	Purge Body	1	
4-4	262992	Cover Plate	1	
4-5	261874	Primer Bulb	1	
4-6	283905	Diaphragm, Meterring	1	
4-7	262993	Gasket	1	
4-8	262994	Diaphragm,Fuel Pump	1	
4-9	282576	Gasket	1	
4-10	261876	E-Ring	1	
4-11	261658	Swivel	1	
4-12	261875	Screw	2	
4-13	264677	Bracket	1	
4-14	261657	Packing	1	
4-15	262996	Screw	4	
4-16	264678	Washer	1	
4-17	261352	Label	1	Choke
4-18	281714	Cap Screw	2	M5x20
4-19	281715	Cap Screw	1	M5x20
4-20	269762	Gasket	1	
4-21	268055	Air Filter Case Ass'y	1	Incl.22-25
4-22	268056	Air Filter Case	1	
4-23	268057	Valve	1	
4-24	268157	Sleeve	1	5.5x7.1x6L
4-25	268412	Sleeve	1	5.5x7.1x6.6L
4-26	263345	Packing	1	7.2x11xt1.3
4-27	263942	Washer	1	7.2x12xt0.15
4-28	263815	Stay	1	
4-29	264016	Cap Screw	2	M5x60
4-30	265026	Screen	1	
4-31	265027	Foam Element	1	
4-32	268058	Air Filter Cover Ass'y	1	Incl.33-35
4-33	268059	Air Filter Cover	1	
4-34	281438	Knob	1	
4-35	261734	Snap Ring	1	#5
4-36	284954	Fuel Tank Ass'y	1	Incl.37-47
4-37	281439	Fuel Tank	1	
4-38	281564	Fuel Tank Cap Ass'y	1	Incl.39
4-39	269377	Gasket	1	
4-40	282538	Fuel Pipe Pick-up Ass'y	1	Incl.41-47
4-41	282539	Fuel Pipe Ass'y	1	Incl.42-45
4-42	268065	Grommet	1	
4-43	261690	Fuel Pipe	1	160L
4-44	261590	Breather	1	
4-45	261117	Clip	1	

4. BC3021H-RS-01
 CARBURETOR, FUEL TANK



Ref. No.	Part No.	Part Name	Q'ty	Remarks
4-46	264653	Filter Ass'y	1	
4-47	261117	Clip	1	
4-48	261117	Clip	1	
4-49	281441	Stand	1	

5. BC3021H-RS-01
ACCESSORIES



Ref. No.	Part No.	Part Name	Q'ty	Remarks
5-1	210418	Box Spanner	1	13x19x(+)
5-2	022865	Double-ended Wrench	1	8x10
5-3	210181	Lever Handle	1	3.5x170L
5-4	220534	Blade Cover	1	
5-5	227910	3-Teeth Blade	1	
5-6	232226	Semi-Auto Head (L)	1	
5-7	233234	Instruction Manual	1	
5-8	233326	Instruction Manual	1	
5-9	523302	Parts List	1	BC3021H-RS-01
5-10	219432	Wrench	1	4mm
5-11	219433	Wrench	1	5mm